



HP9121 Controller PCB Sheet 2

09121-66510




HP9121 Controller PCB Sheet 3

09121-66510




HP9121 Controller PCB Sheet 4


09121-66510





HP9121 Controller PCB Sheet 3 09121-66510





HP9121 Controller PCB Sheet 6 09121-66510



























Sony Single-Head Disk Drive Sheet (4) FC-6 PCB












Sony Single-Head Disk Drive Spindle Motor Sheet (2) CMK-4SEX



Sony Floppy Drive Spindle Motor Shet ()



Sony Floppy Drive Spindle Motor Shat(2)



Sony Floppy Drive Spindle Motor Short 3